

ULTRABAN IS INCOMPATIBLE WITH BLEACH AND BLEACH RESIDUE – THE PRESENCE OF BLEACH BEFORE, DURING OR AFTER APPLICATION NEUTRALIZES THE EFFECTIVENESS OF THE ULTRABAN SOLUTION

COMPOSITE DECKING APPLICATION GUIDE

This guide assumes that:

- Surfaces have been pre-cleaned with UltraMean or UltraMean-2.
- Chlorine Bleach has not been used.
- The surface is now clean and has dried completely.

Do not proceed with applying UltraBan if a heavy dew, rain or other risk of wash-off is present for at least two (2) hours after application.

Do not apply UltraBan onto a hot deck surface. Hot surfaces speed drying but reduce the micro-pore penetration of UltraBan.

Application TOOLS AND EQUIPMENT options

- Garden pump sprayer
- Mop bucket
- Sponge Mop – New is recommended but a very clean mop that has been washed with soap and water then rinsed well to remove residual chemicals left in the mop head from other cleaning agents may be used.*

* Sponge Mops used to apply UltraBan may be cleaned with hot soap and water (while still wet and before UltraBan dries in the surface).

Spray Applications

1. Always wear personal protection equipment when applying chemicals. EYE PROTECTION, GLOVES, SIMPLE FACE MASK etc. are recommended. Consult MSDS regarding material handling instructions.
2. Shake UltraBan container well or pour into a pail and mix with drill type mixer.
3. Pour UltraBan into garden pump sprayer
4. Cover and protect plants in the overspray area
5. Spray apply UltraBan to surface completely wetting surface
6. After 10 minutes or before UltraBan dries, pre-wet sponge mop with UltraBan and “back-wipe” surfaces to remove excess material and ensure application of a “uniform film of protection”
7. A second wiping of the surface with the UltraBan soaked sponge mop is acceptable and recommended. Additional passes over the surface will decrease coverage rate and will eventually create a film build that is no longer invisible.

UltraBan material recovered from the sponge mop may be reused if retained in the original “sealed” container

Mop/Wipe-On Applications

1. Always wear personal protection equipment when applying chemicals. EYE PROTECTION, GLOVES, SIMPLE FACE MASK etc. are recommended. Consult MSDS regarding material handling instructions.
2. Shake UltraBan container well or pour material into a pail and mix with drill type mixer
3. Cover and protect plants in the drip or run-off area
4. Dip mop into pail to wet the sponge surface
5. Remove excess material from mop to prevent drips and waste
6. Apply UltraBan to surface - completely wetting surface
7. After 10 minutes or before UltraBan dries, pre-wet sponge mop with UltraBan and “back-wipe” surfaces to insure application of a “uniform film of protection”
8. A third repeat wiping of the surface with the UltraBan soaked sponge mop is acceptable and recommended. Additional passes over the surface will decrease coverage rate and will eventually create a film build that is no longer invisible

Railings and Spindles

Because of the waste associated with spraying railings and spindles, wiping UltraBan onto these surfaces with a sponge or sponge roller is recommended.

General Care and Maintenance

A mild solution of UltraMean-2 will clean the surface without damaging the “Dried Film Protection” of UltraBan. Severe or “staining spills” on the surface requiring heavy cleaning should have UltraBan re-applied to the surface to re-establish the “Invisible Shield” or “Dried Film Protection” of UltraBan.

DO NOT USE BLEACH BASED CLEANERS ON TREATED SURFACES!